



GENERAL DIFFUSER KIT INSTALLATION:

- 1) TAKE OUT ALL LAMPS FROM LAMP HOLDERS.
- 2) TAKE ALL CHASSIS EXTENSIONS' SCREW OUT BY UNSCREWING THEM.
- 3) PUT DIFFUSER BRACKET ON CHASSIS EXTENSION. ALIGN HOLES ON DIFFUSER BRACKET AND CHASSIS EXTENSION. **(NOTE: IF LOCATION OF CHASSIS EXTENSION IS FURTHER BACK, CLOSER TO WALL, USE BACK HOLES ON THE BRACKET AND VICE VERSA).** SCREW DIFFUSER BRACKET AND CHASSIS EXTENSION TOGETHER TO CHASSIS.
- 4) REPEAT STEP 2 & 3 FOR ANOTHER CHASSIS EXTENSION AT THE OTHER END OF CHASSIS.
- 5) SCREW ACRYLIC DIFFUSER STRIP TO DIFFUSER BRACKETS BY USING PROVIDED SCREW AND NUT.
- 6) REPEAT STEP 3 THROUGH 5 FOR ANOTHER SIDE(S) OF CHASSIS THAT REQUIRE DIFFUSER KIT.