

North American Television Remote Control IR Codes

Power On	0x24020df
Power Off	0x240fa05
Guide	0x240906f
Scan	0x240609f
Source	0x240e01f
ATSC/NTSC	0x24010ef
Volume Up	0x24030cf
Volume Down	0x2403ac5
Exit	0x24058a7
Select	0x2409a65
Channel Up	0x24042bd
Channel Down	0x240708f
Menu	0x240807f
CC	0x240d827
Mute	0x24028d7
Jump	0x240e817
Sleep	0x2407a85
Info	0x2408a75
Display	0x2400af5
0	0x240ea15
1	0x240a857
2	0x2406897
3	0x24050af
4	0x24018e7
5	0x2409867
6	0x240b24d
7	0x24008f7
8	0x240a25d
9	0x2404ab5
Dash	0x2401ae5
List	0x240c03f

Favorite	0x24022dd
Format	0x24040bf
Lang	0x24000ff
Freeze	0x240d02f
VGA	0x24006f9
AV	0x2408679
S-Video	0x24046b9
HDMI	0x240c639
Component	0x24026d9
Antenna/Air	0x240a659
Cable	0x2406699

